



BABYBJÖRN®

Booster Chair

The easy way to grow



Correct sitting height at the table

The booster chair is perfect for when your child grows out of the high chair and wants to sit on a proper chair.



Small and portable

The booster chair is ideal for restaurant visits and travel.



Easy to clean

The booster chair's smooth surfaces make it easy to clean – just wipe it with a cloth.

Information

The easy way to grow



Correct sitting height at the table

The BABYBJÖRN Booster Chair is perfect for when your child grows out of his or her high chair and wants to sit on a proper chair, just like mom and dad. The booster chair helps your child sit at the correct height at the table without kneeling or sitting on a cushion, which can slide off. It is easier to focus on the meal and what is happening around the table when your child is sitting on his or her bottom and at the correct height.



Small and portable - weighs just 2.6 lb (1.2 kg)

Make life easier and take your child's favorite seat with you when traveling. The BABYBJÖRN Booster Chair is light enough for your child to carry. It is equipped with a practical handle and is ideal for transport when the family plans to eat out or travel. Why not keep an extra booster chair at grandma and grandpa's so you don't have to take it with you every time?

Aids child development

By the age of three, most children are old enough to leave the high chair and sit by themselves. That's where the BABYBJÖRN Booster Chair comes in. It is the perfect solution to help your child sit at the table at the correct height. When your child gets to sit on a chair just like you do, it strengthens his or her self-esteem: *"I'm big now and can sit by myself!"*



Easy to clean

The BABYBJÖRN Booster Chair is extremely easy to clean – just wipe it with a cloth. There are no inaccessible corners where bits of food can collect, and there is no seat cushion to wash. Smooth surfaces and a stylish design made with durable, Swedish-produced plastic.



Stackable and versatile

The BABYBJÖRN Booster Chair can be stacked and takes up a minimal amount of space at restaurants, cafés and daycare centers.

"As ideal for mealtimes as it is for drawing or playing at the table!"

Anna, 33

Child-safe design

When your child is sitting securely, it is easier to focus on the meal and activities around the table. That's why we paid particular attention to the following key details:



The unique two-stage lock prevents children from releasing the BABYBJÖRN Booster Chair when it is strapped to the chair.



The non-slip straps and mini pads underneath ensure that the booster chair remains firmly positioned on the chair. The ribbed seat surface makes the seat less slippery.

Fits most chairs



The BABYBJÖRN Booster Chair can be fixed onto most chairs and will quickly become your child's favorite place to sit, both at home and away. It does not leave any unsightly marks on the seat or cushion of the chair being used.



Top Swedish quality

The BABYBJÖRN Booster Chair is made in Sweden from top quality recyclable plastic. It is PVC-free and contains no phthalates or BPA (bisphenol A).

[Find out more about BABYBJÖRN and safe plastics. \(1\)](#)

Specifications

Age

The BABYBJÖRN Booster Chair is recommended for children three years old and up.

Materials

The product is made from recyclable plastic and does not contain any PVC or BPA (bisphenol A). The BABYBJÖRN Booster Chair is made from PP and TPE (non-slip mini pads). Swedish design and manufacture.

Product care

Wipe with a damp cloth and use a mild cleaning agent. The product can be used outdoors.

Safety

The product complies with the Standard Consumer Safety Specification for Booster Seats, ASTM F2640-10.

Technical information

Width/length/height: 13.7 x 13.7 x 5.5 in/35 x 35 x 14 cm

The booster chair raises the child by 3 in/8 cm

Weight: 2.6 lb/1.2 kg

Keep in mind!

Fasten the product onto the chair properly and make sure that the straps are tightened; they should not hang loose under the chair. Always check that the product is firmly and securely fastened on the chair before the child sits on it. The straps should be retracted and the clasp fastened when the product is not in use.

The BABYBJÖRN Booster Chair fits most chairs. Use only on chairs with four legs and a backrest. Not for use on bar stools, folding chairs or chairs with a round seat.

Under [Questions and answers \(2\)](#) you will find the most frequently asked questions about BABYBJÖRN Booster Chair.


FAQ

How do I use the BABYBJÖRN Booster Chair?

- 1) Release the booster chair attachment system by pressing the two-stage lock (a black knob on the back of the booster chair). The attachment strap is now unlocked and you can feed it out to the required length.
- 2) Place the BABYBJÖRN Booster Chair on an appropriate* chair and secure the attachment system by fastening the clasp and then pressing-and-twisting the black knob to tighten the straps.
- 3) Make sure that the straps are properly tightened – they should not hang loose under the chair. Always check that the booster chair is firmly and securely fastened on the chair before letting a child sit on it.

Remember! Use the attachment system at all times!

*The BABYBJÖRN Booster Chair fits most chairs. For safety reasons, use only on chairs with four legs and a backrest. Not for use on bar stools, stools, folding chairs or chairs with a round seat.



Under [Questions and answers \(3\)](#) you will find the most frequently asked questions about BABYBJÖRN Booster Chair.

Links

1. <http://dev.babybjorn.se/us/about-us/our-responsibilities/product-safety/safe-plastics/>
2. <http://dev.babybjorn.se/us/customer-service/faq/kitchen/booster-chair/>
3. <http://dev.babybjorn.se/us/customer-service/faq/kitchen/booster-chair/>